

Issue Summary Noisy elliptical machine operation

Applies To All Elliptical machines

Detailed Problem Description	Creaking, squeaking, clicking, grinding or pinging from stride assemblies during operation. (May only occur after prolonged use; 10 minutes or more.)
Procedure Overview	1) Level the equipment
1) Leveling	<p>For the highest accuracy, use a carpenter's level to ensure the equipment is level in both planes (front to back and side to side).</p> <p>If available, strip of wood laid across the stabilizing feet from the front to rear feet on either side will give a platform for a level to be oriented front-to-rear, or side-to-side for most accurate adjustment of the leveling feet.</p> <p>A bullseye level can be placed on the floor near the center of the equipment to spot check for the level of the installation surface, and rough level adjustments can be made based on this reading.</p> <p>Use the adjustable leveling feet at the front and rear corners of the machine to compensate for unlevel flooring.</p>